






General Settings View

When you first run the calculator, press the **OPT** and touch the **⚙️** button in the Options Selection view toolbar to show the "General Settings" view. In this view you can customize your calculator:



- Toggle to select the Platinum or Classic calculator model.
- Toggle to select the Vertical or Horizontal calculator layout.
- Toggle to lock the RLM-12 in the current orientation or rotate it dynamically.
- Toggle to highlight or not keyboard alternate functions when **f** or **g** are pressed.
- Set the delete digit **←** or the normal **CLX**.
- Set to "ON" to prevent the iPad's to sleep when the RLM-12 Finance Center is running.
- Set the payment mode Same than press **g** **END** or **g** **BEG**.
- Set the Dates format to "M.DY" or "D.MY". Same than **g** **M.DY** or **g** **D.MY**.
- Set comma or point for decimal separator. The thousands separator will be the other.
- Set the number of decimals to show. Same than **f** and **0** to **9**.
- Enable or disable the key-click sound feedback when any button is touched.
- Adjust the key-click volume level (the volume is relative to the device level).
- Enable or disable the sound effects feedback when some actions are performed.
- Adjust the sound effects volume level (the volume is relative to the device level).
- Adjust the display brightness.

This help view can be showed pressing  and selecting  button in the Options Selection toolbar, or pressing   directly in the calculator's keyboard.

Press any of the help topic buttons at the left list to show an explanation of each subject.

For further information and support visit our product page at 'www.rlmttools.com' or write an email to 'support@rlmttools.com'.