


# General Settings View

This view shows all the customization and settings of the calculator. To show it, touch the keyboard's **[PREF]** key.



The screenshot shows the 'General Preferences' menu with the following settings and their descriptions:

Setting	Value	Description
Old Skin	OFF	Select the skin of the calculator between the OLD and NEW looks.
RPN Entry Logic	OFF	Select entry mode between the ALG mode and RPN mode.
Operation Precedence	OFF	Set operation precedence ON or OFF. When ON the priority is “^”, “x” or “÷” and “+” or “-”.
Number Format	FIX	Select the number format: FIX, SCI, ENG or ALL.
N° of Decimals	2	Set the number of digits to show after the decimal point (from 0 to 9).
Decimal Separator	.	Set comma or point for decimal separator and thousands separator.
Date Format	M.DY	Select the dates entry format to "M.DY", "D.MY" or "Y.MD".
Angles Units	DEG	Select angle units to "RAD", "DEG", "GRAD", "DMS" or "%".
Disable Auto-Lock	ON	Set "ON" to prevent the device to sleep when the app is running in front.
Haptic Feedback	ON	Toggle to have an haptic action when a button is touched.
Highlight 'Shift'	ON	Toggle to highlight or not keyboard alternate functions when the Shift key is pressed.
Click Sound	ON	Enable or disable the key-click sound feedback when any button is touched.
Click Volume	9	Adjust the key-click volume level (the volume is relative to the device level).
Effects Sound	ON	Enable or disable the sound effects feedback when some actions are performed.
Effects Volume	5	Adjust the sound effects volume level (the volume is relative to the device level).
Display Brightness	9	Adjust the display brightness from 1 to 9.

Buttons: Default, Done